



Instructions/Assembly EZ833CDSP & EZ86CDSP

EZ Dispenser 3 Pack Heavy Duty Window Kit & EZ Dispenser Patio Heavy Duty Window Kit

- 1. Affix Three strips of double sided tape to two sides and bottom of window, u-shape**
- 2. Pull out window film, w/ pre-taped top edge, out of canister, and affix to top of the window**
- 3. Slide cutter down on side of the canister to trim window film to width of window**
- 4. Unfold window film and affix to double sided tape**
- 5. Shrink window film with hair dryer and trim excess film from sides**